

Getting Started

5000 DigitalinXIP AVoIP and Arranger Controller Installation

Step 1 - Configure a Network Switch for AV Multicasting

- [VIDEO](#) - Network Switch Requirements
- [DOCUMENT](#) - Network Switch Settings and Approved Switch List
- [DOCUMENT](#) - Switch Manufacturer Startup / Running Config Settings

Step 2 - Connect all Digi IP Devices to the AV Network Switch

- [VIDEO](#) – Network Cabling Requirements
- [DEVICE MANUAL](#) – DigitalinXIP 5000 Series

Step 3 - Connect all AV devices to the Digi IP encoders and decoders

- Connect HDMI AV Sources to the **IPEX5001** Encoders
- Connect TV Displays and Monitors to the **IPEX5002** Decoders

Step 4 - Connect the IPEXAR-5000 Arranger Controller to the AV Network Switch and Login

- [VIDEO](#) – Connecting to the Arranger Controller

Once connected to the Arranger controller web server, Digi IP device and system configuration is managed entirely in Arranger

- **SOFTWARE MANUAL** – Can be accessed once logged into Arranger
- **API** – Can be accessed once logged into Arranger

Click [HERE](#) for more Arranger Training Videos Online

Note: You must have a LibAV website login to access the AVOIP training video category online, contact your LibAV sales rep for access

Need more training? [Contact us!](#)